# Move to XYZ-coordinate

The MOVE command allows you to enter exact values for X, Y, or Z (0,0,0) where the first entry is X, the second entry is Y, and the third entry is Z. The X, Y, and Z values will reference from the machine's Hard Home position until the SET HOME and SET SURFACE commands have been selected. At that point the X and Y axis will reference from the Set Home position. The Z value will reference from the surface of the material if the surface has been set.

To Move To A Specific Location.

Press the MOVE hot key.
Enter the desired value for X from the number pad (50.0 for example).




Press ENTER to accept the value.

Enter the desired value for Y from the number pad (-50.0 for example). Press ENTER to accept the value.




Enter the desired value for Z from the number pad (5.0 for example). Press ENTER to accept the value.




When the coordinates have been entered, click on the **Move** button.




When pushing the **Move** button the machine will move to the new coordinates. If for some reason you do not want to move to the entered coordinates, hit the **Cancel** key.

After the move you will see the new coordinates in the top part of the pendent window:




**Return to the keypad overview.**
**Continue to the table of contents.**

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
**https://manuals.cyborg-engravers.com/doku.php?id=en:x200:move_to_xyz_key&rev=1745316735**

Last update: **2025/04/22 12:12**