Cyborg X-200 Desktop Engraving machine - Table of contents

Introduction

- General instructions - Safety instructions
  - Safety before all – General safety instructions
  - List of warning, mandatory and prohibition signs
  - Warning labels
  - Machine label
- Technical Specifications
- Handling and use

Chapter 1 – Getting started

1.1. Features

- 1.1.1. Rotary engraving
- 1.1.2. Diamond scratching

1.2 Component names and functions

- 1.2.1. Front view
- 1.2.2. Rear view
- 1.2.3. Virtual keypad

Chapter 2 – Installation and setup

2.1. Installation environment

2.2. Unpacking

- 2.2.1. Unpacking
- 2.2.2. Checking the contents of the box

2.3. Cable connections

- 2.3.1. Checking the supply voltage
- 2.3.2. Connecting the power cable
- 2.3.3. Connecting the X-300 to your computer or network

2.4. Installing the software

- 2.4.1. System requirements

- 2.4.2. Configuring the PC's ethernet port
- 2.4.3. Installing the Cyborg virtual pendent
- 2.4.4. Registering and starting the Cyborg pendent software
- 2.4.5. Installing the “Symmetry” engraving software
- 2.4.6. Using other third party software

Chapter 3 – Preparing and executing an engraving job

3.1. Switching the power on and off

- 3.1.1. Switching the power on
- 3.1.2. Switching the power off

3.2. Securing the engraving material onto the engraving table

- 3.2.1. Using the standard included flat engraving table
- 3.2.2. Using the “MultiMat” sheet
- 3.2.3. Using the optional “quick lock vise”

3.3. Setting up a tool

- 3.3.1. How to use the optional cutter calibration stand
- 3.3.2. Installing an engraving tool
- 3.3.3. Installing a scoring tool
- 3.3.4. Installing a diamond scratch tool
- 3.3.5. How to remove a tool from the spindle

3.4. Engraving with nosecone or without nosecone

- 3.4.1. Engraving with floating nosecone
  - 3.4.1.1. Calibration of the nosecone and the optional cutter stand
  - 3.4.1.2. How to use the depth limiting nosecone
  - 3.4.1.3. How to use the spindel spring pressure
- 3.4.2. Engraving without floating nosecone
  - 3.4.2.1. Defining the plate surface
  - 3.4.2.2. How to enter the engraving depths in Symmetry
  - 3.4.2.3. Locking the spring pressure to engrave without nosecone

3.5. How to cut materials

- 3.5.1. Materials rotation speed and feed
- 3.5.2. Two-way engraving metals
- 3.5.3. Adjusting feeds and speeds
- 3.5.4. Pause button
- 3.5.5. Cancelling the engraving job
- 3.5.6. Restarting the engraving job

3.6. Controlling the X-300 using the ‘virtual keypad’

- 3.6.1. Keypad overview
  - Introduction - General overview
  - Function keys
  - Settings screen
- 3.6.2. Setting and saving origin points

Chapter 4 – Maintenance and cleaning

4.1. Cleaning – a must to prolong your machine’s lifetime

4.2. Periodical maintenance

- 4.2.1. daily maintenance
- 4.2.2. weekly maintenance
- 4.2.3. monthly maintenance
- 4.2.4. annual maintenance

4.3. Advanced maintenance

- 4.3.1. Replacing the spindle belt
- 4.3.2. Greasing the leadscrews
- 4.3.3. How to open the electronics drawer

Chapter 5 – Troubleshooting

5.1. The machine does not initialize

5.2. The spindle does not rotate

5.3. The engraving results are poor

5.4. No connection between machine and computer

Chapter 6 – Options

- 7.1. Quick lock vise
- 7.2. Jigs for the quick lock vise
- 7.3. Output signal for switching on and off an external device at the beginning and the end of a job

Appendices

A. Thesaurus: a glossary with specific terms about computerized engraving as being used in this manual.

B. G-code and M-code protocol for the Cyborg controller.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x200:table_of_contents&rev=1745144755

Last update: **2025/04/20 12:25**