# Cyborg X-200 Desktop Engraving machine - Table of contents


## Introduction

- General instructions - Safety instructions
  - Safety before all – General safety instructions
  - List of warning, mandatory and prohibition signs
  - Warning labels
  - Machine label
- Technical Specifications
- Handling and use

## Chapter 1 – Getting started

### 1.1. Features

- 1.1.1. Rotary engraving
- 1.1.2. Diamond scratching

### 1.2 Component names and functions

- 1.2.1. Front view
- 1.2.2. Rear view
- 1.2.3. Virtual keypad

## Chapter 2 – Installation and setup

### 2.1. Installation environment

### 2.2. Unpacking

- 2.2.1. Unpacking
- 2.2.2. Checking the contents of the box

### 2.3. Cable connections

- 2.3.1. Checking the supply voltage
- 2.3.2. Connecting the power cable
- 2.3.3. Connecting the X-300 to your computer or network

### 2.4. Installing the software

- 2.4.1. System requirements

- 2.4.2. Configuring the PC's ethernet port
- 2.4.3. Installing the Cyborg virtual pendent
- 2.4.4. Registering and starting the Cyborg pendent software
- 2.4.5. Installing the “Symmetry” engraving software
- 2.4.6. Using other third party software


# Chapter 3 – Preparing and executing an engraving job


### 3.1. Switching the power on and off

- 3.1.1. Switching the power on
- 3.1.2. Switching the power off

### 3.2. Securing the engraving material onto the engraving table

- 3.2.1. Using the standard included flat engraving table
- 3.2.2. Using the “MultiMat” sheet
- 3.2.3. Using the optional “quick lock vise”

### 3.3. Setting up a tool

- 3.3.1. How to use the optional cutter calibration stand
- 3.3.2. Installing an engraving tool
- 3.3.3. Installing a scoring tool
- 3.3.4. Installing a diamond scratch tool
- 3.3.5. How to remove a tool from the spindle

### 3.4. Engraving with nosecone or without nosecone

- 3.4.1. Engraving with floating nosecone
  - 3.4.1.1. Calibration of the nosecone and the optional cutter stand
  - 3.4.1.2. How to use the depth limiting nosecone
  - 3.4.1.3. How to use the spindel spring pressure
- 3.4.2. Engraving without floating nosecone
  - 3.4.2.1. Defining the plate surface
  - 3.4.2.2. How to enter the engraving depths in Symmetry
  - 3.4.2.3. Locking the spring pressure to engrave without nosecone

### 3.5. How to cut materials

- 3.5.1. Materials rotation speed and feed
- 3.5.2. Two-way engraving metals
- 3.5.3. Adjusting feeds and speeds
- 3.5.4. Pause button
- 3.5.5. Cancelling the engraving job
- 3.5.6. Restarting the engraving job

### 3.6. Controlling the X-300 using the ‘virtual keypad’


- 3.6.1. Keypad overview
  - Introduction - General overview
  - Function keys
  - Settings screen
- 3.6.2. Setting and saving origin points


# Chapter 4 – Maintenance and cleaning

### 4.1. Cleaning – a must to prolong your machine’s lifetime

### 4.2. Periodical maintenance


- 4.2.1. daily maintenance
- 4.2.2. weekly maintenance
- 4.2.3. monthly maintenance
- 4.2.4. annual maintenance


### 4.3. Advanced maintenance


- 4.3.1. Replacing the spindle belt
- 4.3.2. Greasing the leadscrews
- 4.3.3. How to open the electronics drawer


# Chapter 5 – Troubleshooting


### 5.1. The machine does not initialize

### 5.2. The spindle does not rotate

### 5.3. The engraving results are poor

### 5.4. No connection between machine and computer

### 5.5. The engraved data are not correctly positioned on the plate


---

# Chapter 6 – Options


### 6.1. Quick lock vise

### 6.2. Jigs for the Quick lock vise

# Appendices

## A. Thesaurus: a glossary with specific terms about computerized engraving as being used in this manual.

## B. G-code and M-code protocol for the Cyborg controller.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
**https://manuals.cyborg-engravers.com/doku.php?id=en:x200:table_of_contents&rev=1759314571**

Last update: **2025/10/01 12:29**