Jogging the spindle

	**Jog to the left (X-) and to the back (Y+)** Press the  key to jog the spindle to the rear. The jog speed is determined jog speed bar setting.
	**Jog to the right (X+) and to the back (Y+)** Press the  key to jog the spindle to the left. The jog speed is influenced by the jog speed bar setting.
	**Jog to the left (X-) and to the front (Y-)** Press the  key to jog the spindle to the right. The jog speed is determined by the jog speed bar setting.
	**Jog to the right (X+) and to the front (Y-)** Press the  key to jog the spindle to the front. The jog speed is influenced by the jog speed bar setting.

Use the jog speed bar to change the speed 

. Click on the rabbit or on the turtle, or click on the dial.

Return to the keypad overview.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x300:jog_keys&rev=1664308250

Last update: **2022/09/27 21:50**