Diagonal jogging keys

Jog to the left (X-) and to the back (Y+) Push the key to jog the spindle to the left and to the rear simultaneously. The jog speed is determined by the hot key setting.
Jog to the right (X+) and to the back (Y+) Push the key to jog the spindle to the right and to the rear simultaneously. The jog speed is influenced by the hot key setting.
Jog to the left (X-) and to the front (Y-) Push the key to jog the spindle to the left and to the front simultaneously. The jog speed is determined by the hot key setting.
Jog to the right (X+) and to the front (Y-) Push the key to jog the spindle to the right and to the frontsimultaneously. The jog speed is influenced by the hot key setting.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x300:jog_xy_keys&rev=1641475115

Last update: **2022/01/06 14:18**