Jog spindle up to the rear



Press and hold the Z-AXIS JOG ARROW  to raise the spindle.

Use the jog speed bar to change the speed 

. Click on the rabbit or on the turtle, or click on the dial.

Return to the keypad overview.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x300:jog_y_keys&rev=1664136552

Last update: **2022/09/25 22:09**