# Jog spindle to the rear



Press and hold the Y-AXIS JOG ARROW  to jog the spindle to the back.

Use the jog speed bar to change the speed 

. Click on the rabbit or on the turtle, or click on the dial.

**Return to the keypad overview.**
**Continue to the table of contents.**

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
**https://manuals.cyborg-engravers.com/doku.php?id=en:x300:jog_y_keys&rev=1664307476**

Last update: **2022/09/27 21:37**