# Jogging the spindle

| | |
|---|---|
|  | **Jog to the left (X-) and to the back (Y+)**<br>Press the  key to jog the spindle to the rear.<br>The jog speed is determined jog speed bar setting. |
|  | **Jog to the right (X+) and to the back (Y+)**<br>Press the  key to jog the spindle to the left.<br>The jog speed is influenced by the jog speed bar setting. |
|  | **Jog to the left (X-) and to the front (Y-)**<br>Press the  key to jog the spindle to the right.<br>The jog speed is determined by the jog speed bar setting. |
|  | **Jog to the right (X+) and to the front (Y-)**<br>Press the  key to jog the spindle to the front.<br>The jog speed is influenced by the jog speed bar setting. |

Use the jog speed bar to change the speed 

. Click on the rabbit or on the turtle, or click on the dial.

**Return to the keypad overview.**
**Continue to the table of contents.**

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
**https://manuals.cyborg-engravers.com/doku.php?id=en:x300:jog_y_keys&rev=1664308074**

Last update: **2022/09/27 21:47**