# Move back / Move forward x times

| | |
|---|---|
|  | If you push this key during an engraving job, the spindle will lift and move **back** either one vector or one character, depending upon the software used. |
|  | If you push this key during an engraving job, the spindle will lift and move back either ten vectors or ten characters, depending upon the software used. |
|  | If you push this key during an engraving job, the spindle will lift and move back either 25 vectors or 25 characters, depending upon the software used. |
|  | If you push this key during an engraving job, the spindle will lift and move **forward** either one vector or one character, depending upon the software used. |
|  | If you push this key during an engraving job, the spindle will lift and move forward either ten vectors or ten characters, depending upon the software used. |
|  | If you push this key during an engraving job, the spindle will lift and move forward either 25 vectors or 25 characters, depending upon the software used. |

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
**https://manuals.cyborg-engravers.com/doku.php?id=en:x300:move_back-forward_x_times&rev=1664093691**

Last update: **2022/09/25 10:14**