Move back / Move forward x times

	If you push this key during an engraving job, the spindle will lift and move **back** either **one** vector or one character, depending upon the software used.
	If you push this key during an engraving job, the spindle will lift and move **back** either **ten** vectors or ten characters, depending upon the software used.
	If you push this key during an engraving job, the spindle will lift and move **back** either **25** vectors or 25 characters, depending upon the software used.
	If you push this key during an engraving job, the spindle will lift and move **forward** either **one** vector or one character, depending upon the software used.
	If you push this key during an engraving job, the spindle will lift and move **forward** either **ten** vectors or ten characters, depending upon the software used.
	If you push this key during an engraving job, the spindle will lift and move **forward** either **25** vectors or 25 characters, depending upon the software used.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x300:move_back-forward_x_times&rev=1664093783

Last update: **2022/09/25 10:16**