Diagonal parking keys

 +	**Park the spindle in the upper left corner** Press the ⇧ + ↖ keys to park the spindle to the left and to the rear simultaneously.
 +	**Park the spindle in the upper right corner** Press the ⇧ + ↗ key to park the spindle to the right and to the rear simultaneously.
 +	**Park the spindle in the lower left corner** Press the ⇧ + ↙ key to park the spindle to the left and to the front simultaneously.
 +	**Park the spindle in the lower right corner** Press the ⇧ + ↘ key to park the spindle to the right and to the front simultaneously.

Return to the keypad overview.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x300:parking&rev=1664308950

Last update: **2022/09/27 22:02**