# Parking keys

| | |
|---|---|
|  | **Park the spindle in the rear**<br>Press the ⇧ + ↑ keys to park the spindle to the left and to the rear simultaneously. |
|  | **Park the spindle to the right**<br>Press the ⇧ + → key to park the spindle to the right and to the rear simultaneously. |
|  | **Park the spindle to the left**<br>Press the ⇧ + ← key to park the spindle to the left and to the front simultaneously. |
|  | **Park the spindle in the front**<br>Press the ⇧ + ↓ key to park the spindle to the right and to the front simultaneously. |

**Return to the keypad overview.**
**Continue to the table of contents.**

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
**https://manuals.cyborg-engravers.com/doku.php?id=en:x300:parking&rev=1664309149**

Last update: **2022/09/27 22:05**