Move spindle up



Press and hold the Z-AXIS JOG ARROW  to raise the spindle. Press the JOG SPEED  key to change the jogging speed.

Return to the keypad overview.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x300:raise_spindle_key&rev=1664096273

Last update: **2022/09/25 10:57**