# Spindle Test




The Spindle Test will test the controller output to the Spindle Motor. The spindle motor will stay active until the key is pressed again.

## Activating Spindle Test

Press the SPINDLE TEST  key.

Keypad Display “Activating Spindle ....”

Press SPINDLE TEST  again stops the Spindle Test.

**Note:**

Pressing the CANCEL  key will also stop the spindle test.

**Return to the keypad overview.**
**Continue to the table of contents.**

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
**https://manuals.cyborg-engravers.com/doku.php?id=en:x300:spindle_test_key&rev=1664310849**

Last update: **2022/09/27 22:34**