3.4.2. Engraving without floating nosecone

- In this chapter we explain how the plate surface (Z=0.0) can be defined (see 3.4.2.1).
- Then you will read which procedure has to be followed to enter engraving depths in Symmetry. (see 3.4.2.2.)
- After that follows the explanation how to mechanically prepare the machine to work without nosecone. (see 3.4.2.3.)
- Finally the execution of the engraving job with locked spring pressure. (zie 3.4.2.4.)

- 3.4.2.1. Defining the plate surface
- 3.4.2.2. How to enter engraving depths in Symmetry
- 3.4.2.3. Locking the spindle spring to engrave without nosecone
- 3.4.2.4. Executing a job without using the nosecone

Continue to 3.4.2.1. Defining the plate surface.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x200:engraving_without_floating_nose&rev=1744981372

Last update: **2025/04/18 15:02**