

"Pointer Ruler Guides" menu option

The **Pointer Ruler Guides** menu option is a simple checkbox:

- Activating this will turn your mouse cursor into a crosshair, allowing the operator to move or place the cursor in a precise position with reference to other objects on the lay-out.
- Deactivating will have your cursor return to the standard arrow-shaped Windows cursor.

From:

<https://manuals.cyborg-engravers.com/> - **cyborg-engravers**

Permanent link:

https://manuals.cyborg-engravers.com/doku.php?id=de:symmetry:option_pointer_ruler_guides

Last update: **2023/06/16 09:42**

