

6.1 The Cyborg X200 quick lock vise.

6.1.1. Installing the X200 quick lock viseRegistering the virtual pendent software

In order to be able to use the virtual pendent software, it has to be registered. In the top bar of the Cyborg virtual pendent right click on the “?”, and then on the “register” menu option.

	If a window such as the one here on the left appears then something is wrong with your ethernet connection, or with the ethernet cable, or the X-200 has not been switched on.
	

the machine’s mac address in the “customer number” field. This is a unique code which is linked to the X-200 cnc controller.
On the USB memory stick which was supplied with your machine you will find the release code which you have to type into the “Registration Code” field. Here on the left is an example of an application window with a correct registration code: If your registration code is correct, the virtual software will accept it and release the product. |

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x200:quick_lock_vise&rev=1759323025

Last update: **2025/10/01 14:50**