Go home

The “Go Home”hot key functions as a return to 0,0 soft home and tool lift key.Press the GO HOME hot key
.Keypad status line display:
“Going Home …”

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x300:go_home_key&rev=1664053095

Last update: **2022/09/24 22:58**