# Park spindle in the rear



The PARK Y+ function  +  will move the spindle assembly to the very rear of the engraving table.

**Activating Park Y+.**

Press the SHIFT  key and then the X-Y+-AXIS ARROW  to park the spindle in the rear left corner of the engraving table.
Keypad status bar displays:
“Parking ...”

**Return to the keypad overview.**
**Continue to the table of contents.**

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
**https://manuals.cyborg-engravers.com/doku.php?id=en:x300:koppeling&rev=1664138442**

Last update: **2022/09/25 22:40**