
Park spindle in the rear



The PARK Y+ function + will move the spindle assembly to the very rear of the engraving table.

Activating Park Y+.

Press the SHIFT key and then the X-Y+-AXIS ARROW to park the spindle in the rear left corner of the engraving table.
Keypad status bar displays:
“Parking …”

Return to the keypad overview.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x300:koppeling&rev=1664138496

Last update: **2022/09/25 22:41**