Shift

Pressing the SHIFT hot key before pressing any desired hot key will allow you to toggle between the Normal Hot Key and the Shifted Hot Key functions. When the SHIFT key has been pressed, the SHIFT ARROW will change colour to indicate you are in Shifted Mode.

Return to the keypad overview.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x300:shift_key&rev=1664136827

Last update: **2022/09/25 22:13**