Move spindle down 1 mm



Press the SHIFT  key and then the Z-AXIS JOG DOWN ARROW  to lower the spindle.

Use the jog speed bar to change the speed 

. Click on the rabbit or on the turtle, or click on the dial.

Return to the keypad overview.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=en:x300:shift_lower_spindle_key&rev=1664135449

Last update: **2022/09/25 21:50**