

# Go home



The "Go Home" hot key functions as a return to 0,0 soft home and tool lift key. Press the GO HOME hot key.

Keypad status line display:  
"Going Home ..."

**Return to [the keypad overview](#).**  
**Continue to [the table of contents](#).**

From:  
<https://manuals.cyborg-engravers.com/> - **cyborg-engravers**

Permanent link:  
[https://manuals.cyborg-engravers.com/doku.php?id=es:x300:go\\_home\\_key](https://manuals.cyborg-engravers.com/doku.php?id=es:x300:go_home_key)

Last update: **2022/09/24 23:04**

