Option de menu "Curseur en forme de croix"

The **Pointer Ruler Guides** menu option is a simple checkbox:

- Activating this will turn your mouse cursor into a crosshair, allowing the operator to move or place the cursor in a precise position with reference to other objects on the lay-out.
- Deactivating will have your cursor return to the standard arrow-shaped Windows cursor.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=fr:symmetry:option_pointer_ruler_guides&rev=1664369154

Last update: **2022/09/28 14:45**