Déballer et contrôler le contenu de la boîte

Déballer

- Mettez la boîte sur le sol, à côté de la table sur laquelle vous voulez installer la machine
- Ouvrez la boîte

```
Retirez délicatement la machine et les accessoires et placez-les sur votre
table ou votre paillasse.
Vérifiez le contenu de votre livraison à l’aide de la liste de contrôle dans
le paragraphe ci-dessous.
Débarrassez votre table ou votre paillasse et rangez tous les accessoires à
proximité.
Attention : c'est un travail à 2 personnes ! pour sortir la machine de la
boîte et la placer sur l'établi ou la table.
```

After having unpacked, we advise you not to throw away the packing material. You might need it later when you need to move the machine to a new location or eventually, to ship the machine back to your vendor for service or repair.

Check the contents of the box


Image	Item description	Quantity	Checkbox
	Engraving machine Cyborg X-300	1	
	Cutter stand (cutters and knobs not included)	1	



Image	Item description	Quantity	Checkbox
	Cutter 3.175 mm x 125 mm, cutting width 0.2 mm	1	
	Cutter knob 3.175 mm	1	
	Vacuum hose 2 m	1	
	Wrench for cutter knob (2 mm)	1	
	Power Cord	1	
	CAT6A ethernet cable	1	
	USB stick with software and registration code for Pendent software and for Symmetry engraving software	1	
	Sticky mat 300 mm x 200 mm	1	

Image	Item description	Quantity	Checkbox
	Cable for vacuum or auxiliary output	1	

Continue to the X-300 cable connections.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=fr:x300:box_contents&rev=1700581372

Last update: **2023/11/21 16:42**