Menukeuze "Cursor in kruisvorm"

De menukeuze **Cursor in kruisvorm** is een eenvoudig vinkvakje:

- ***Activeren*** this will turn your mouse cursor into a crosshair, allowing the operator to move or place the cursor in a precise position with reference to other objects on the lay-out.
- ***Deactiveren*** will have your cursor return to the standard arrow-shaped Windows cursor.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=nl:symmetry:option_pointer_ruler_guides&rev=1655386759

Last update: **2022/06/16 15:39**