De Zoom-functie

The **Zoom**-functie is enkel toegankelijk via de drie iconen in de **iconenbalk** bovenaan het Symmetry-scherm, of via de overeenkomstige **snelkoppeling** aan de linkerkant van uw hoofdscherm.

The Icon bar

■ Previous Zoom State

 After having zoomed in one or several times, you can return to the previous zoom state by clicking on the **Previous Zoom State** icon.

■ Zoom In

 When selecting the **Zoom In** icon, you can select a specific area in your job screen by clicking opposite corners of the area you want to view. Any combination of corners (top left and bottom right, top right and bottom left, etc.) will work.

■ Zoom Out

 Clicking on the **Zoom Out** icon will have you return to the full view of your current engraving job.

The Shortcuts

There is a single zoom shortcut  available, which will work differently, depending whether you selected a single text line or not.

■ Line selected

With a text line selected, clicking the zoom shortcut will have Symmetry zoom in onto the text line in question.

■ No line selected

Clicking the zoom shortcut will have Symmetry zoom ou to the entire job.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=nl:symmetry:zoom&rev=1655296142

Last update: **2022/06/15 14:29**