Go home



The “Go Home” hot key functions as a return to 0,0 soft home and tool lift key.
Press the GO HOME hot key.

Keypad status line display:
“Going Home …”

Return to the keypad overview.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=nl:x200:go_home_key&rev=1741720851

Last update: **2025/03/11 20:20**