Beweeg de spindel omhoog



Press and hold the Z-AXIS JOG ARROW 

to raise the spindle.

Use the jog speed bar to change the speed 

. Click on the rabbit or on the turtle, or click on the dial.

Return to the keypad overview.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=nl:x200:raise_spindle_key&rev=1741726215

Last update: **2025/03/11 21:50**