

Installatie omgeving

Vooraleer je je nieuw aangekochte machine uitpakt zorg je ervoor dat je een geschikte plek kiest om hem te plaatsen. Volg de volgende richtlijnen:

- Gebruik een robuuste en stabiele tafel om de machine op te plaatsen.
- Zorg dat deze tafel of die werkbank op een soliede vloer staat.
- De hoogte van de tafel moet zo zijn dat er comfortabel en veilig aan gewerkt kan worden. Als je rechtstaand aan de machine wilt werken, zorg dan voor een goede tafelhoogte, zodat dat je niet voorover moet buigen.
- There should be at least 20 cm of free space left, right and behind the machine.
- Do not put any object on the machine covers.
- The room temperature has to be between 10°C and 40°C.
- Use the original power cable which was supplied with the machine and if possible do not use an extension cord.
- If you have to use an extension cord, use only one, and make sure the cord is not longer than the distance you have to cover. Also make sure this extension cord has the correct wire section.
- Make sure your wall outlet is properly secured with a circuit breaker.
- Use a power outlet with a decent ground connection.

Continue to [unpacking the X-300](#).

Continue to [the table of contents](#).

From:
<https://manuals.cyborg-engravers.com/> - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=nl:x300:installation_environment&rev=1669730971

Last update: **2022/11/29 15:09**

