De graveerjob herstarten of verderzetten

De graveerjob verderzetten

Om de graveerjob te starten moet die job eerst in het geheugen van de virtuele pendent geladen zijn. Als dat het geval is, is de naam zichtbaar in de centrale statusbalk in het virtuele toetsenbord.

Om de job te starten, klik op het  ikoon. Na op dit ikoon geklikt te hebben start de job en wordt het “pauze” ikoon getoond in plaats van het “Start” ikoon.

Om eender waar de job te pauzeren, klik ophet Pauze  ikoon. Na het klikken van dit ikoon pauzeert de job en het “ga verder” ikoon wordt afgebeeld in plaats van het “Pause” ikoon.

Om de job verder te zetten, klik op het “verdergaan”  ikoon. De job wordt verdergezet waar hij gepauzeerd werd en het “verdergaan” ikoon wordt vervangen door het “pauze” ikoon.

Herhalen van een juist gegraveerde job

If you need to engrave the same job several times, you engrave it once, put a new plate on the table, and you hit the Start  icon twice.
you can repeat this as many times as you like, the machine will repeat the last engraved job everytime.

Continue to an overview of the virtual keypad.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=nl:x300:restarting_job_console&rev=1670163913

Last update: **2022/12/04 15:25**