Software Installatie

Systeem Vereisten

Je hebt de volgende hardware en software nodig om jobs in Symmetry te kunnen ontwerpen en uitvoeren.

- Microsoft Windows 10 of 11
- 1 PC, toetsenbord, muis en beeldscherm. Als Symmetry samen met de Cyborg virtuele pendent moet werken, en je PC moet deel uitmaken van een LAN, dan heeft je PC 2 ethernet poorten nodig.
- Een vrije USB poort om de Symmetry software te installeren.
- Een Cyborg graveermachine op de jobs op uit te voeren

Installatie procedure

- **Stap 1: Start de installer**
  Steek de meegeleverde memory stick in de USB poort van je computer.
  Blader in je usb geheugenstick en dubbelklik op het bestand ‘Symmetry-2.4.0.5.exe“. Het getal dat je ziet na het ‘Symmetry’ woord geeft het versienummer aan.
- **Stap 2: Kies de gewenste installatie locatie.**
  Standaard zal de installatiesoftware “C:\Symmetry” aanbevelen als installatiemap. Desgewenst, of indien de policy van uw organisatie dat vereist kun je ook installeren in een andere map zoals “C:\Program Files\Symmetry” of in een map naar keuze. Om dat te doen klik je op de “Browse…” knop en je kiest een map.
  Klik daarna “Next >”.
- **Stap 3: Kies componenten.**
  In dit stadium kun je enkel de Symmetry software zelf kiezen. Omdat deze optie vereist is, staat ze in het grijs, en je kunt ze dus niet de-selecteren. Klik op de “Install” knop.
  De groen balk geeft aan wanneer de installatie afgewerkt is.
  Klik daarna op “Close”.
- **Stap 4: Creëer een snelkoppeling ikoon op je bureaublad.**
  ingeval de installatie niet zelf automatisch een snelkoppeling creëerde op je bureaublad, of indien dat ikoon per ongeluk gewist werd, kun je Windows Verkenner openen en bladeren naar de Symmetry programma map. Binnen deze map klik je met de rechter muisknop op het bestand ‘Symmetry.exe’ en daarna op de keuze ‘snelkoppeling maken’. Sleep deze nieuwe snelkoppeling naar je bureaublad.

De Symmetry software is nu volledig operationeel, behalve voor het uitvoeren van graveerjobs naar de machine. Je kunt wél jobs ontwerpen, openen, jobs wijzigen enzovoort, maar je kunt ze nog niet graveren. Om ze te kunnen graveren moet Symmetry *geregistreerd* worden.

Registration

Symmetry provides you with a unique **Engraver Code**. This is the Mac address of the machine controller. The Mac address is a code consisting of letters and numbers, which is unique to any computer device. As such, the code is not transferable from one computer to another.

Every Cyborg engraving machine is supplied with a memory stick containing the release codes for both supplied softwares (Pendent software and Symmetry) for your specific machine.

- **Step 1: Preparation.**
  Make sure your computer is connected to the engraving machine and the ethernet parameters have been set properly. Your engraving machine has to be switched on.
- **Step 2: Open the registration window.**
  Launch the Symmetry software and click the “New Job” button. A new job screen is opened, along with the “Autolayout” window. Close the “Autolayout” by clicking the [X] in the upper right corner, then left-clicking on the Help menu, then on the “**Register components**” option.
- **Step 3: Enter the release code:**
  You will see a code after the text “Engraver Code:” In the example below this code is 682719E4B5F2. This is the Mac address of the controller inside your engraver. This is a unique code. There is no other engraver, printer, pc or any other computerized device with the same mac address worldwide. So the engraver code you see will be different for each individual engraving machine.
  The release code for Symmetry is identical to the release code for the pendent software. You will be able to find this code on the USB memory stick which you did receive with your machine. In order to be able to enter the release code in the Symmetry registration window the machine has to be switched on and connected to the PC, which has to be configured with the correct IP-address.
- After having entered the release code click the ‘Apply’ button. Symmetry will inform you that the software is now registered, and that you will have to close the program and restart it in order to work with the registered licence.

Continue to using third party software.
Continue to the table of contents.

From:
https://manuals.cyborg-engravers.com/ - **cyborg-engravers**

Permanent link:
https://manuals.cyborg-engravers.com/doku.php?id=nl:x300:symmetry:installation&rev=1669804678

Last update: **2022/11/30 11:37**